

#9249 Housing Control Tips

Accessory Package

This package contains the following replacement control tips



Installation: Use pliers to gently remove the old control tip if glued in place. A small drop of super-glue can be used "if necessary" to secure the new tip on the control shaft end.

Ikelite Underwater Systems
50 West 33rd Street
Indianapolis, IN 46208

General questions e-mail: ikelite@ikelite.com


317-923-4523

www.ikelite.com

Control Tips 9249-02-1208

Ikelite Maintenance Kit

Use the enclosed allen wrenches provided to check tightness on all housing controls periodically or before each dive trip. Access the long set screws through a slit in the top of the nylon sleeve as shown.



Ikelite Underwater Systems
50 West 33rd Street
Indianapolis, IN 46208

General questions e-mail: ikelite@ikelite.com

317-923-4523

www.ikelite.com

Maintenance Kit-01-0109

IKELITE PHOTOCASE

The Ikelite Photocase is an airtight and watertight equipment case. It features a fold down handle for easy storage. To insure a good seal, periodically check the o-ring sealing surfaces to make sure they are free of cuts, abrasions, or foreign debris that could hamper the seal. No lubricant is needed on this o-ring.

The pressure purge underneath the handle must be kept snug tight. This Photocase is designed to purge off inside pressure build-up automatically. If you are unable to open the case after air travel or when returning from high elevations, simply loosen the purge screw one or two turns to vent the air pressure build-up. After 20 seconds, close the purge snugly and open the case.

Since the Photocase is airtight, exercise caution in high humidity environments. Moist air could be trapped inside the case if left open for prolonged periods. Regular use of silica-gel moisture absorbing packets is recommended. Gel packets are available at most professional camera stores.

Most scuffs and stains can be removed quickly with household cleanser and a soft sponge. Do not use any type of brush that will scratch the surface.

Do not store the Photocase near any heat producing source. Do not store the Photocase in a small enclosed area during warm sunny days. Heat build-up can permanently damage the case and its contents.

IKELITE LIMITED WARRANTY

The Ikelite Photocase is warranted against any manufacturing defects for a period of one (1) year from the date of purchase.

Defective products should be returned pre-paid to Ikelite. Ikelite will, at its discretion, repair or replace such products and return to customer pre-paid. All other claims, of any nature, including but not limited to bulb failure, are not covered. Except as mentioned above, no other warranty expressed or implied, applies to this product.

IKELITE UNDERWATER SYSTEMS

50 W. 33rd St.
Indianapolis, IN 46208 USA
317-923-4523

General questions e-mail: ikelite@ikelite.com

Additional product information is available on our website at:

www.ikelite.com