


Ikelite #4100.6 EV Controller

supplemental instructions



Ikelite Housings

These supplemental instructions list most of the non-pre-flash digital camera models housed by Ikelite. This supplemental instruction manual will assist you in setting the EV Controller switches described in the instruction manual.

Non Ikelite Housings

When using the EV Controller on another manufacturer's housing with a camera not listed, check with housing or camera manufacturer to determine if the camera has pre-flash.

Non Pre-Flash Cameras (cont.)

Canon:

All Canon Cameras have Pre-Flash unless otherwise noted.
G3, G5, G6, G7, G9, G10, G11, Pro 1, A530, A540, A550,

A570IS, A640, A700, A710IS, S5, SX1, SX10, SX110, SX200IS

1. If the camera's flash is set to Manual Mode in the camera menu, there is NO preflash.
2. If the EV Controller is connected to the housing with a sync cord and the housing hot-shoe is connected to the camera, there is NO pre-flash.

Nikon 5000, 8400, 8800

1. If the EV-Controller is connected to the housing with a sync-cord and the housing hot-shoe is connected to the camera, there is NO pre-flash.

Olympus 5000, 5050, 5060, 7070, 8080

1. If the camera's flash is set to Slave Mode in the camera menu, there is NO preflash.
2. If the EV Controller is connected to the housing with a sync cord and the housing hot-shoe is connected to the camera, there is NO pre-flash.

Sony DSC-F717, DSC-V1, DSC-828

1. If the EV Controller is connected to the housing with a sync cord and the housings hot-shoe is connected to the camera, there is NO pre-flash.

NOTE: If your camera is not listed, please refer to your camera owner's manual for flash information.

Pre-Flash Digital Cameras

Most digital cameras that Ikelite offers a housing for, have Pre-Flash, unless otherwise noted.

Non Pre-Flash Digital Cameras

Fuji

F-810

Kodak

DX3900, DX4900, DX7590, Z7590

Nikon

Coolpix 950, 990, 995
Coolpix 4500, 5700, 8400, 8700
Coolpix 5400 (only when wired to the EV Controller)

Sony

MVC-FD-81, 83, 85, 88, 90, 100, 200
MVC-CD200, CD300
MVC-FD81, FD85, FD83, FD88, FD90, FD95, FD97
DSC-S60, S70, S75, S85, S90
DSC-V1, V3



Ikelite Underwater Systems
50 W 33rd Street
Indianapolis, IN 46208 USA

When returning products send
"attn. Repair Dept."

"general questions" e-mail:
ikelite@ikelite.com

www.ikelite.com